

HANGING INSTRUCTIONS



PLEASE CAREFULLY READ AND FOLLOW THESE INSTALLATION INSTRUCTIONS. NOTE THE PRODUCT WARRANTY IS VOID SHOULD THE WALLPAPER BE INSTALLED CONTRARY TO THESE INSTRUCTIONS. IF YOU HAVE ANY QUERIES OR ISSUES PLEASE CONTACT US IMMEDIATELY AND BEFORE HANGING THE PRODUCT,

PREPARATION MAKE SURE THE SURFACE IS SMOOTH AND CLEAN

Proper surface preparation is critical for a high quality wallcovering installation. Any imperfections in the wall to be covered may read through to the surface of the installed material. Surface must be clean, smooth, dry, structurally sound and uniform in colour. Any existing imperfections in the wall surface, such as cracks, taped joints, dents or nail heads should be sealed and sanded smooth. Ballpoint ink, grease, crayon or any other foreign matter should be cleaned or removed.

Wall surfaces should not exceed 5% moisture content as measured by moisture meter. Apply product when the relative humidity in the installation area does not exceed 40% and the temperature is above 12 degrees Celsius. Those conditions should be maintained in the areas of both storage and installation for three days prior to and after the installation. If there are any questions concerning the surface to be covered, a test installation of at least one strip applied three days in advance of the main installation is recommended. Use only a lead pencil for marking the wallcovering on the reverse side of the dry erase surface.

When installing WriteOn Whiteboard Wallpaper, great care should be exercised when trimming wallcovering around electrical outlets. Due to the ferrous content in the wallpaper it may act as a conductor of electricity. Do not allow this material to come into contact with any exposed wires. Turn off electricity when working around outlets. Cut around all electrical openings so adequate clearance is allowed between material and electrical wiring and boxes.

CHECK THE MATERIAL

Material should be carefully inspected BEFORE CUTTING to confirm the correct material and quantity ordered has been shipped. If there are different lot numbers, organise for installation with the same lot numbers together. Number the rolls for installing in sequence.

APPLICATION

All plasterboard surfaces must be primed with an undiluted good quality primer/sealer such as Zinser 123, and must have cured for a MINIMUM of 24 hours prior to WriteOn installation.

Other surfaces: Contact Hillmorr for recommendations, info@hillmorr.com.au / 02 9166 8967

Use a laser level when installing either vertically or horizontally. Apply a uniform coat of clay based or clear based adhesive to the wall where each strip is to be installed, overlap the edges at least 40mm. Repaste any dry areas or if there is a delay in hanging.

We suggest hanging the whiteboard wallcovering horizontally to eliminate seams in the writing area. Overlapping and double cutting will produce the best seaming results. For full wall applications, it is recommended a full width first strip be centered on the wall in the most likely writing area (approximately 80cm-90cm from the floor). A plumb or level line must be established for an acceptable installation. Take the wallcovering to the wall. Do not crease the wallcovering when handling. Keep the material free of any dirt or abrasiveness that may damage or scratch it.

It is critical that any foreign particles on the back of the wallcovering be removed before installation. Never puncture air bubbles underneath the surface.

Remove air pockets or paste lumps, working toward the uncovered wall. Use a wallcovering smoothing tool wrapped in a clean, soft cloth to ensure protection of the writing surface. The writing surface can be damaged by tools with hard, sharp or abrasive edges. If the surface is scratched, marker residue may accumulate in that opening and leave a permanent mark. Work the wallcovering from middle to the outside edge. Take care not to "overwork" the surface to avoid paste lumping.

When cutting seams, use the proper cutting tool to avoid scoring the wall. Carefully roll or press the seams down, being careful not to overwork the seam. Change blades often to insure clean cuts. If any frayed threads are present at the seams, cut them with a clean sharp razor blade. Do not pull threads to remove them. Vertical seams should not occur less than 150mm from any outside or inside corner. After hanging one horizontal strip of dry erase material, examine the installed wallcovering for colour uniformity and overall appearance.

IMPORTANT

Any problems with damaged material or installation must be communicated to HILLMORR Wallcoverings info@hillmorr.com.au or call 02 9166 8967 BEFORE proceeding with the installation. HILLMORR is not responsible for the appearance or performance of the wallpaper not applied according to these instructions.

Remove all excess adhesive immediately using a clean soft sponge and clean water. Do not use abrasive cleaners or dirty water. Change water often to keep it clean. Dry with a clean, soft towel.